**INVICTA**

Function : Hour, Minute, Second, Date and Day

PRESENTATION

Display Elements

Minute Hand
Hour Hand
Second Hand
Day
Date

Control Buttons

Crown Positions:

1. Normal position
2. Quick correction of day / date
3. Correction of hour, minute

*INSTRUCTIONS*
MANUAL
Cal.2824

SETTINGS

Setting the Time, Hour and Minute

1.1 Pull the crown to position 3.

1.2 Turn the crown clockwise to set hour/minute hands to the desired time.

1.3 Push the crown back to position 1.

Please note:
70% of power is saved when the crown is pulled out.

1.1   1.2   1.3

Day Setting

2.1 Pull the crown to position 2.

2.2 Turn the crown clockwise to set the date.

!! Attention !! Never correct date between 10:30pm and 0:00am.

2.3 Push the crown back to position 1.

2.1   2.2   2.3

Day Setting

3.1 Set the crown to position 2.

3.2 Turn the crown anticlockwise to set the day.

3.3 Release the button after completing the setting.

Please note:
Setting wanted language if indicator bilangual.

3.1   3.2   3.3