



Function : Hour, Minute & Second Hands, Date, Day

PRESENTATION



- Display Elements**
- Date
 - Minute Hand
 - Hour Hand
 - Second Hand
 - Day

- Control Buttons**
- Crown Positions:
1. Normal position
 2. Setting of date
 3. Setting of hour, minute, day

**INSTRUCTIONS
MANUAL**

**Cal.7003L/7003N
Cal.7004N/7004P**



SETTINGS

Time Setting

- 1.1 Pull out the crown to position 3.
- 1.2 Turn the crown to set the hour / minute hands to the desired time.
- 1.3 Push the crown back to position 1.



Date Setting (Quick Mode)

- 2.1 Pull out the crown to position 2.
- 2.2 Turn the crown clockwise. Continue to turn the crown until the desired date is set.
- 2.3 Push the crown back to position 1.

Please note:
An extreme acceleration in setting the date with quick mode can create a false date indication. The synchronization is re-established by setting the date from 01 till 31 (crown position 2).



Weekday Setting

- 3.1 Set the crown to position 2.
- 3.2 Turn the crown clockwise to advance the day hand until the desired day is set.
- 3.3 Push the crown back to position 1.

Please note:
70% of power is saved when the crown is pulled out.



INFO

Battery: 381 (diameter 11.6mm x 2.15mm)