

Function : Hour, Minute & Second

PRESENTATION

Display Elements

Minute Hand
Hour Hand
Second Hand



Control Buttons

Crown
1. Normal position
2. Setting of hour, minute

INSTRUCTIONS MANUAL Cal.82SO

SETTINGS

Setting the Time

- 1.1 Pull the crown to position 2.
- 1.2 Turn the crown clockwise to set the hour / minute hands to the desired time.
- 1.3 Push the crown back to position 1.



1.1



1.2



1.3

INFO

Winding the Mainspring

- Automatic winding watch can also be hand wound by turning the crown clockwise in position 1.
- Wind several times clockwise and it will start to move naturally.